


STEP ③ 将水管插入饮水水桶内，并将产品紧扣饮水水桶口。

Insert the water pipe into the drinking water bucket and fasten the product tightly to the mouth of the drinking water bucket.



STEP ④ 将杯子放在出水口下，按下开关按键产品出水，再按一次产品停止出水。

Put the cup on outlet, press the switch button products out of the water, again according to the product to stop the water.

指示灯说明

INDICATOR LIGHT DESCRIPTION

○ 按下开关产品开机白色指示灯点亮，再次按下产品关机灯光熄灭；当产品低电量使用时此时的灯光为红色闪烁。

Press the switch and the white indicator light on when the product starts up will be on. Press the button again and the shutdown light will be off. When the product is in low power, the light will flash red.


○ 插上电源此时产品处于充电状态灯光显示为红色，产品充满电时，灯光熄灭。

When the product is plugged in, the light shows red. When the product is fully charged, the light goes out.


○ 产品在充电状态下使用时，按下开关产品开机灯光由红色变为白色；再次按下产品关机灯光变回红色。

When the product is in charge, press the switch and the starting light changes from red to white. Press the product shutdown button again to change the light back to red.

使用说明
INSTRUCTIONS



STEP ① 首次使用前，请先取出包装内容所含的配件，并仔细阅读产品使用说明书。
Before using for the first time, please take out the accessories contained in the package and read the product manual carefully.



STEP ② 将配套的水管插入接管口。
Insert the matching water pipe into the nozzle.



安全注意事项 (请仔细阅读并严格遵守)

Safety Cautions (please read it carefully and follow it strictly)

- 使用和清洁时拔掉电源插头。
Remove the power plug when using and cleaning.
- 请勿将任何危险物放置在产品上。
Do not place any dangerous objects on the product.
- 请勿将产品直接放入水中，以免造成产品损坏及漏电情况发生。
Do not put the product into water to avoid damage or leakage.
- 通电时，电源指示灯将亮起，机身会轻微发热，属正常现象。
When the power is on, the indicator light will be light up and the dehumidifier body will be slightly hot, which is a normal phenomenon.
- 请勿私自拆卸零件，可能会导致产品故障或损坏。
Do not disassemble any parts by yourself to avoid possible failure or damage to the product.
- 通电时，请勿覆盖或遮挡产品，以免发生意外和损伤产品。
Do not cover or block dehumidifier when power is on to avoid possible accident or damage to the product.
- 如发现异常或异味，请即刻拔除电源，并与本公司售后服务部门联系，请勿自行维修，以免发生危险。
Please unplug and contact related after-sales department immediately once abnormal or peculiar smell happened. Do not fix it by yourself to avoid danger.
- 本产品须由本公司认可的单位或技术人员进行更换及维修。
Damaged product should be replaced or repaired by a technician or manufacturer recognized by our company.

故障分析及排除

Fault analysis and elimination

- 问题一：使用时指示灯不亮
Question 1: The indicator does not respond when charging.
原因分析：电池没电或出现故障
Reasons Analysis: Power is not connected or has failed.
处理方法：插上电源重新开机，若仍无法正常工作，请联系售后部门进行产品维修或更换
Solution: If it still cannot work normally, please contact the after-sales department for product repair or replacement.
- 问题二：开机正常，但不出水
Question 2: Normal power on, but no water.
原因分析：水管未连接或堵塞
Reasons Analysis: Water pipe not connected or blocked.
处理方法：检查水管的连接

向物自动上水器 | Bottled Water Pump

Name 产品名称	向物自动上水器	Model 产品型号	DSHJ-S-2004
Water output 出水量	≈1.4L/min	Charging Current 充电电流	610mA
Net Weight 产品重量	278g	Input 额定输入	DC 5V/1A
Size 产品尺寸	104×68×137mm	Battery Capacity 电池容量	2000mAh
Charge Time 充电时长	4h	Standards 执行标准	GB4706.1-2005

产品介绍 INSTRUCTION

