

# Mi Camera 2K (Magnetic Mount) User Manual



Read this manual carefully before use, and retain it for future reference.

## Precautions

---


- The operating temperature range for this camera is between -10°C and 50°C. Do not use this camera in environments with temperatures above or below the specified range.
- The camera is a precision electronic product. In order to ensure its normal operation, do not install the camera in environments with a high humidity nor allow water to get into it.
- To improve the camera's performance, do not place its lens facing or next to reflective surfaces, such as glass windows or white walls, as this will cause the image to appear overly bright in areas close to the camera and darker in areas further away, or cause the camera to produce completely white images.
- Make sure the camera is installed in an area with a strong Wi-Fi signal. Do not install the camera near microwave ovens, and other objects or places that affect its Wi-Fi signal.



- If the charging cable is damaged or broken, it must be replaced with a genuine charging cable purchased from the manufacturer or after-sales service department to avoid safety hazards.

## Product Overview

---

Package Contents: Camera, magnetic base, charging cable, metallic sticker, and user manual






## Installation

---

The camera can be placed on flat surfaces such as desks, dining tables, coffee tables, TV cabinets, etc.

**Note:** The installation height of the camera should not exceed 2 meters, and ensure it is firmly and securely installed.




Illustrations of the product, accessories, and user interface in the user manual are for reference purposes only. The actual product and functions may vary due to product enhancements.

## Installing a MicroSD card

Ensure that the camera is unplugged and insert the MicroSD card into the slot with its contact side facing up.

**Note:** Unplug the camera when installing or removing the MicroSD card. Please use a MicroSD card from a well-known brand with reading and writing speed equal to or higher than U1 and Class 10. The camera can be used without a MicroSD card. However, it cannot save videos nor use the playback and time-lapse photography functions without a card. Therefore, it is recommended to install a MicroSD card.




## How to Use

---

### Turning on

- Connect the charging cable and power adapter, and the camera will turn on automatically after it is plugged in.



- Once the indicator is yellow and you hear a voice notification, the camera is turned on successfully.

**Note:** Please select a power adapter with an output of 5 V/1 A from a reputable manufacturer.

## Indicator status description

- Yellow: Awaiting connection...
- Blinking yellow: Connecting to a network...
- Blinking blue: Connecting to a server...
- Blue: Connected successfully

## Resetting the camera

Use a pin or a similar tool to press and hold the reset button. Once you hear a voice notification the camera has been reset successfully.

**Note:** Resetting the camera will not delete any data from the MicroSD card.





## Connect with Mi Home/Xiaomi Home App

This product works with the Mi Home/Xiaomi Home app\*. Use the Mi Home/Xiaomi Home app to control your device, and to interact with other smart home devices.

Scan the QR code to download and install the app. You will be directed to the connection setup page if the app is installed already. Or search "Mi Home/Xiaomi Home" in the app store to download and install it.

Open Mi Home/Xiaomi Home app, tap "+" on the upper right, and then follow prompts to add your device.

\* The app is referred to as Xiaomi Home app in Europe (except for Russia). The name of the app displayed on your device should be taken as the default.

**Note:** The version of the app might have been updated, please follow the instructions based on the current app version.

Make sure the network connection is stable. The indicator is yellow when the camera is turned on, and then changes into blue once the connection between your camera and app is successful.



41D3F858

## Specifications

---

Name: Mi Camera 2K (Magnetic Mount)

Operating Temperature: -10°C to 50°C

Item Dimensions: 60.0 × 48.0 × 67.5 mm

Wireless Connectivity: Wi-Fi IEEE 802.11 b/g/n 2.4 GHz

Operation Frequency: 2412-2472 MHz

Maximum Output Power: < 20 dBm

Storage Method: MicroSD card

Compatible with: Android 6.0 & iOS 11.0 or above

Model: MJSXJ03HL

Rated Input: 5 V ⎓ 1 A

Focal Length: 3.3 mm

Video Codec: H.265

Resolution: 2304 × 1296

Lens Viewing Angle: 125°

## WARRANTY NOTICE

---

As a Xiaomi consumer, you benefit under certain conditions from additional warranties. Xiaomi offers specific consumer warranty benefits which are in addition to, and not instead of, any legal warranties provided by your national consumer law. The duration and conditions related to the legal warranties are provided by

respective local laws. For more information about the consumer warranty benefits, please refer to Xiaomi's official website <https://www.mi.com/en/service/warranty/>. Except as prohibited by laws or otherwise promised by Xiaomi, the after-sales services shall be limited to the country or region of the original purchase. Under the consumer warranty, to the fullest extent permitted by law, Xiaomi will, at its discretion, repair, replace or refund your product. Normal wear and tear, force majeure, abuse or damage caused by the user's negligence or fault are not warranted. The contact person for the after-sale service may be any person in Xiaomi's authorized service network, Xiaomi's authorized distributors or the final vendor who sold the products to you. If in doubt please contact the relevant person as Xiaomi may identify.

The present warranties do not apply in Hong Kong and Taiwan.

Products which were not duly imported and/or were not duly manufactured by Xiaomi and/or were not duly acquired from Xiaomi or a Xiaomi's official seller are not covered by the present warranties. As per applicable law you may benefit from warranties from the non-official retailer who sold the product. Therefore, Xiaomi invites you to contact the retailer from whom you purchased the product.

## WEEE Information



All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.

## EU Declaration of Conformity



Hereby, Tianjin Hualai Technology Co., Ltd. declares that the radio equipment type [MJSXJ03HL] is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <http://www.mi.com/global/-service/support/declaration.html>

Importer:

Beryko s.r.o.

Na Roudné 1162/76, 301 00 Plzeň

[www.beryko.cz](http://www.beryko.cz)

Manufactured for: Xiaomi Communications Co., Ltd.

Manufactured by: Tianjin Hualai Technology Co., Ltd.

(a Mi Ecosystem company)

Address: 8/F, Huaqiao Chuangye Building, No.10 Jinping Road, Ya 'an Street,

Nankai District, Tianjin City, P.R. China

For further information, please go to [www.mi.com](http://www.mi.com)

User Manual Version: V1.0